



# BAITCASTING REEL COASTAL 153HL



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	G87-7401	R/S PLT	52	G04-0801	L/S PLT SCREW A
6	375-7404	SPACER A	53	G47-3501	L/S PLT SCREW B
7	375-7411	SPACER B	54	B85-3101	O RING A
8	G51-1502	BALL BEARING A	55	B91-1746	L/S PLT SCREW C
9	F03-2201	BEARING RET A	56	F80-0501	PINION SHAFT
10-20	Z01-7438	SPOOL	57	171-5201	O RING B
21	G87-7301	FRAME	58	B17-5401	SPOOL ADJ CAP METAL
22	G54-3401	CLUTCH LEVER PLT A	59	B17-5503	RUBBER WASHER
23	G54-3601	CLUTCH LEVER	60	F57-4404	CAST CONTROL CAP
24	G54-3501	CLUTCH LEVER PLT B	61	G35-7506	DRIVE SHAFT WASHER
25	320-5901	WORM SHAFT RET	62	G05-1901	BUSHING
26	373-1306	WORM SHAFT WASHER	63	G65-2702	DRIVE SHAFT
27	G54-4801	LEVEL WIND GUARD	64	G60-1902	DRIVE SHAFT RET
28	G54-4301	LINE GUIDE	65	E13-4508	DRIVE SHAFT RET SCREW
29	121-4212	LINE GUIDE PAWL	66	G01-0201	CLUTCH TRIP PLT SPRING
30	373-1303	LINE GUIDE WASHER	67	F76-1701	A/R RATCHET
31	F40-2801	PAWL CAP	68	G00-1501	DRIVE GEAR A
32	G12-8201	WORM SHAFT COLLAR	69	G60-2101	DRIVE GEAR B
33	G54-4601	WORM SHAFT	70	F79-6101	EARED WASHER
34	G54-5401	STABILIZER BAR	71	G42-8501	DRAG WASHER
35	G54-5303	FRONT PLT	72	F79-6301	KEY WASHER A
36	B36-0401	FRONT PLT SCREW	73	G45-5801	DRAG WASHER B
37	F83-4701	BALL BEARING COLLAR	74	B36-0303	KEY WASHER B
38	G52-0502	BALL BEARING B	75	G01-1401	GEAR SHAFT COLLAR
39	F99-7401	CLUTCH CAM	76	F99-9803	ROLLER CLUTCH
40	G60-1802	YOKE PLT	77	G52-0502	BALL BEARING D
41	G60-2201	CLUTCH CAM SPRING	78	B55-3801	BEARING WASHER
42	G00-9701	CLUTCH CAM SCREW	79	F02-8201	CLICK LEAF SPRING HOLDER
43	G26-1101	CLUTCH TRIP PLT	80	F03-2401	BRAKE CLICK SPRING
44	371-6905	CLUTCH TRIP PLT WASHER	81	150-8901	SPRING WASHER
45	320-1402	CLUTCH TRIP PLT RET	82	B97-4901	SPACING SLEEVE
46	F99-8201	YOKE	83	G65-2202	STAR DRAG
47	G59-7301	YOKE SPRING	84	150-9001	FRICITION WASHER
48	G60-2002	PINION GEAR	85	G59-8702	HANDLE
49	E21-9701	BEARING RET B	91	B86-2104	HANDLE NUT
50	G46-6201	BALL BEARING C	92	E44-0008	HANDLE NUT PLT
51	G60-1507	L/S PLT	93	351-1801	HANDLE NUT PLT SCREW

**BAITCASTING REEL**

**TEAM DAIWA LUNA 203L/253L**




Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	F79-8111	R/S OUTER RING	57	G52-7801	STABILIZER BAR
2	G28-8809	DIAL	58	F55-0501	STABILIZER BAR RET
3	G28-7801	RING	59	320-5901	WORM SHAFT RET
4	G28-8101	CLICK SPRING	60	373-1303	WORM SHAFT WASHER
5	G53-8701	IDLE GEAR	61	F79-5801	WORM SHAFT HOLDER A
6	F79-8201	RET	62	F79-5101	LEVEL WIND GUARD
7	G60-9002	R/S PLT	63	F79-5201	LINE GUIDE
8	G50-0901	PIN	64	121-4212	LINE GUIDE PAWL
9	F79-8301	O RING A	65	375-4101	LINE GUIDE PAWL WASHER
10	G53-8801	DIAL HOLDER	66	341-5901	PAWL CAP
11	G28-8402	MAGNET HOLDER	67	F79-5501	WORM SHAFT HOLDER B
12	G00-4601	MAGNET HOLDER RET	68	F84-9101	WORM SHAFT
13	375-7404	SPACER A	69	F57-5601	DRIVE SHAFT WASHER
14	375-7411	SPACER B	70	G53-8001	BALL BEARING D
15	F57-4303	SPACER C	71	F84-9002	DRIVE SHAFT
16	G43-1101	BALL BEARING A	72	F99-8001	DRIVE SHAFT RET
17	E21-9701	BEARING RET A	73	E13-4501	DRIVE SHAFT RET SCREW
18-27	Z01-7613	SPOOL	74	F76-1701	A/R RATCHET
28	G82-9601	FRAME	75	F79-5901	DRIVE GEAR A
29	F79-3305	CLUTCH LEVER PLT A	76	F99-8501	DRIVE GEAR B
30	F99-7501	CLUTCH LEVER	77	F79-6101	EARED WASHER
31	F79-3203	CLUTCH LEVER PLT B	78	G42-8501	DRAG WASHER
32	F79-3401	BEARING RET B	79	F79-6301	KEY WASHER A
33	G43-1001	BALL BEARING B	80	B36-0303	KEY WASHER B
34	F99-7401	CLUTCH CAM	81	G05-6301	GEAR SHAFT COLLAR
35	F99-7701	YOKE PLT	82	F55-2703	ROLLER CLUTCH
36	F79-3801	YOKE PLT SCREW	83	G05-6201	DRAG COLLAR
37	F79-4401	CLUTCH SPRING PIN	84	150-8901	DRAG SPRING WASHER
38	G60-8901	CLUTCH SPRING	85	373-7810	SPACING SLEEVE
39	F99-7901	CLUTCH TRIP PLT	86	G70-3802	STAR DRAG
40	F79-4701	CLUTCH TRIP LEVER SPRING	87	F85-0401	HANDLE COLLAR
41	F79-4601	CLUTCH TRIP LEVER PIN	88	G70-5501	HANDLE
42	371-6905	CLUTCH TRIP LEVER WASHER	89	341-5805	HANDLE NUT
43	320-1402	CLUTCH TRIP LEVER RET	90	040-3208	HANDLE NUT PLT
44	F99-8201	YOKE	91	353-8301	HANDLE NUT PLT SCREW
45	F79-4901	YOKE SPRING			
46	F99-8301	PINION GEAR			
47	E21-9701	BEARING RET C			
48	G43-0901	BALL BEARING C			
49	G14-6507	L/S PLT			
50	B67-9302	R/S PLT SCREW			
51	F80-0501	PINION SHAFT			
52	171-5201	O RING B			
53	B17-5401	SPOOL ADJ CAP METAL			
54	B17-5503	RUBBER WASHER			
55	F57-4403	CAST CONTROL CAP			
56	F55-0501	STABILIZER BAR RET			

TDLUNA253L Special Parts		
Key No.	Parts No.	Parts Name
18-27	Z01-7616	SPOOL
28	G82-9401	FRAME
30	F99-7601	CLUTCH LEVER
35	F99-7801	YOKE PLT
49	G14-6506	L/S PLT
57	G52-7901	STABILIZER BAR
62	F81-9901	LEVEL WIND GUARD
68	F81-9401	WORM SHAFT

# TEAM DAIWA ZILLION 100HLA / 100SHLA




Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	G88-4801	L/S PLT	54	G79-1401	DRAG WASHER A
2	G81-9801	ROLLER CLUTCH	55	F90-4902	KEY WASHER A
3	B42-1601	BEARING RET A	56	G71-1101	DRAG WASHER B
4	G53-8001	BALL BEARING A	57	G35-8501	KEY WASHER B
5	G89-4401	CLICK LEAF SPRING A	58	G01-1401	GEAR SHAFT COLLAR
6	F74-4101	PINION SHAFT	59	B86-1703	BALL BEARING D
7	B17-5401	SPOOL ADJ CAP METAL	60	B55-3801	BEARING WASHER
8	B17-5503	RUBBER WASHER	61	F02-8201	CLICK LEAF SPRING HOLDER
9	F83-3907	CAST CONTROL CAP	62	F03-2401	CLICK LEAF SPRING B
10	G80-1503	FRAME	63	150-8901	SPRING WASHER
11	F83-4701	BALL BEARING COLLAR	64	373-7810	SPACING SLEEVE
12	G26-0702	CLUTCH LEVER PLT A	65	G79-2504	STAR DRAG
13	G26-0802	CLUTCH LEVER PLT B	66	F85-0402	HANDLE COLLAR
14	G43-1002	BALL BEARING B	67	G88-4501	HANDLE
15	F99-7401	CLUTCH CAM	68	G79-3302	HANDLE NUT
16	G26-0901	CLUTCH LEVER	69	040-3209	HANDLE NUT PLT
17	G80-1701	CLUTCH CAM PLT	70	353-8301	HANDLE NUT PLT SCREW
18	G00-9701	CLUTCH CAM SCREW	71	G04-0805	R/S PLT SCREW A
19	G80-1801	CLUTCH TRIP PLT	72	G04-0801	R/S PLT SCREW B
20	371-6906	CLUTCH TRIP PLT WASHER	73	G26-1501	FRONT PLT
21	320-1402	CLUTCH TRIP PLT RET	74	G01-1702	STABILIZER BAR
22	G79-0202	DRIVE SHAFT	75	G26-1608	R/S PLT
23	F05-5601	BALL BEARING C	76	G26-1802	RIGHT SET PLT
24	G75-5201	DRIVE SHAFT WASHER A	77	351-0906	RIGHT SET PLT SCREW
25	320-5901	DRIVE SHAFT RET A	78	F57-7802	BRAKE ADJ KNOB
26	G80-1901	DRIVE SHAFT RET B	79	F05-1701	BRAKE CLICK SPRING
27	E13-4503	CLUTCH LEVER SCREW	80	F57-7901	SET PLT SCREW
28	G85-0401	DRIVE SHAFT RET SCREW	82	E16-7101	SET PLT SPRING
29	G79-4106	PLT A	83	F61-3401	BRAKE DIAL RET A
30	G79-5706	PLT B	84	B33-9801	BRAKE DIAL RET B
31	G31-8503	PLT SCREW A	85	F63-7701	BRAKE DIAL WASHER
32	G61-1501	PLT SCREW B	86	F71-7702	MAGNET HOLDER
33	G80-2001	CLUTCH CAM SPRING	87	B54-3201	MAGNET HOLDER RET RING
34	F50-5701	CLUTCH PLT SCREW	88	F57-4303	SPACER B
35	G79-0501	DRIVE SHAFT RET SPRING	89	375-7411	SPACER A
36	F99-8201	YOKE	90	375-7404	BEARING METAL WASHER
37	G85-0301	YOKE SPRING	91	G49-8602	BALL BEARING E
38	G88-4901	PINION GEAR	92	E21-9701	BEARING RET B
39	G41-0301	LINE GUIDE	93-103	Z01-8069	SPOOL
40	G01-0701	WORM SHAFT HOLDER A	104	F44-0201	CLUTCH CAM SPRING WASHER
41	G79-0701	WORM SHAFT	105	G85-0701	CLUTCH PLT WASHER
42	F64-8301	WORM SHAFT HOLDER B	106	320-5901	CLUTCH PLT RET
43	F83-6502	WORM SHIELD	107	G68-4801	STABILIZER BAR WASHER
44	B71-5601	WORM SHAFT HOLDER C			
45	F65-5501	WORM SHAFT WASHER			
46	320-5901	WORM SHAFT RET			
47	121-4212	LINE GUIDE PAWL			
48	373-1303	LINE GUIDE PAWL WASHER			
49	342-4807	PAWL CAP			
50	G80-2201	A/R RATCHET			
51	G86-3501	DRIVE SHAFT WASHER B			
52	G80-2301	DRIVE GEAR			
53	G79-1301	EARED WASHER			

### TDZLN103SHLA Special Parts

Key No.	Parts No.	Parts Name
1	G88-4801	L/S PLT
10	G80-1503	FRAME
29	G79-4106	PLT A
30	G79-5706	PLT B
38	G88-4901	PINION GEAR
52	G80-2301	DRIVE GEAR
93-103	Z01-8069	SPOOL


# STEEZ 103HLA

Please order by parts number, not key number



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	G81-4301	R/S PLT	56	G89-7101	PINION GEAR
2	F57-7901	SET PLT SCREW	57	E21-9701	BEARING RET B
3	E16-7101	SET PLT SPRING	58	G46-6202	BALL BEARING D
4	F77-0704	BRAKE DIAL WASHER A	59	G89-7301	L/S PLT
5	G75-7402	BRAKE ADJ KNOB	60	G26-2301	CLUTCH CAM PLT B
6	B33-9801	BRAKE DIAL RET A	61	G04-0814	L/S PLT SCREW A
7	F63-7701	BRAKE DIAL WASHER B	62	G04-0815	L/S PLT SCREW B
8	F05-1701	BRAKE CLICK SPRING	63	G04-0801	L/S PLT SCREW C
9	F61-3401	BRAKE DIAL RET B	64	F26-2701	CLICK LEAF SPRING A
10	G81-4501	RIGHT SET PLT	65	G01-5501	PINION SHAFT
11	G75-7701	MAGNET HOLDER	66	B17-5401	SPOOL ADJ CAP METAL
12	351-0906	RIGHT SET PLT SCREW	67	B17-5503	RUBBER WASHER
13	G75-7801	MAGNET HOLDER RET	68	G77-4701	CAST CONTROL CAP
14	375-7404	SPACER A	69	320-5901	DRIVE SHAFT RET A
15	375-7411	SPACER B	70	G35-5203	DRIVE SHAFT WASHER
16	G18-5101	SPACER C	71	G46-6202	BALL BEARING E
17	G51-1503	BALL BEARING A	72	G81-3801	DRIVE SHAFT RET B
18	F03-2201	BEARING RET A	73	E13-4503	CLUTCH LEVER SCREW
19-28	Z01-7768	SPOOL	74	G87-5801	DRIVE SHAFT RET B SCREW
29	G81-3402	FRAME	75	G75-5401	CLUTCH TRIP PLT SPRING
30	G75-4401	CLUTCH LEVER PLT A	76	G75-5001	DRIVE SHAFT
31	G75-4501	CLUTCH LEVER	77	G75-6001	A/R RATCHET
32	G75-4301	CLUTCH LEVER PLT B	78	G75-6101	DRIVE GEAR A
33	320-5901	WORM SHAFT RET	79	G87-8301	DRIVE GEAR WASHER
34	F65-5501	WORM SHAFT WASHER	80	G81-4101	DRIVE GEAR B
35	B71-5601	WORM SHAFT HOLDER	81	F79-6102	EARED WASHER
36	F83-6502	LEVEL WIND GUARD	82	G42-8501	DRAG WASHER A
37	G75-5701	LINE GUIDE	83	F79-6303	KEY WASHER A
38	121-4212	LINE GUIDE PAWL	84	G45-5801	DRAG WASHER B
39	373-1303	LINE GUIDE WASHER	85	B36-0306	KEY WASHER B
40	F40-2801	PAWL CAP	86	G01-1401	GEAR SHAFT COLLAR
41	G46-6202	BALL BEARING B	87	G81-9801	ROLLER CLUTCH
42	G01-0701	WORM SHAFT COLLAR	88	G75-6301	BALL BEARING F
43	G85-0901	WORM SHAFT	89	B55-3801	BEARING WASHER
44	G35-8702	STABILIZER BAR	90	F02-8201	CLICK LEAF SPRING HOLDER
45	G75-6802	FRONT PLT	91	F03-2401	CLICK LEAF SPRING B
46	G52-0503	BALL BEARING C	92	150-8901	SPRING WASHER
47	G51-7301	CLUTCH CAM	93	373-7810	SPACING SLEEVE
48	G81-3601	CLUTCH CAM PLT A	94	G77-5102	STAR DRAG
49	G81-3901	CLUTCH CAM SPRING	95	F85-0401	HANDLE COLLAR
50	G00-9701	CLUTCH CAM SCREW	96	G89-7201	HANDLE
51	G81-3701	CLUTCH TRIP PLT	97	G77-9201	HANDLE NUT PLT
52	G53-9401	CLUTCH TRIP PLT WASHER	98	G83-5501	HANDLE NUT PLT SCREW
53	320-5901	CLUTCH TRIP PLT RET	99	G77-9101	HANDLE SCREW
54	G35-7901	YOKE	100	375-4104	BRAKE DIAL WASHER C
55	G35-8001	YOKE SPRING			

# SWEEPFIRE 3550R/ 4050R




Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	W56-0501	FRONT DRAG KNOB	45	W46-7601	DRAG KNOB SCREW CAP
1-3	W56-0601	SPOOL	46	W56-0801	BODY
4	W38-0302	MAIN SHAFT	47	W48-7301	HANDLE LOCK SCREW
5	W34-0201	BAIL HOLDER NUT	48	W34-4702	HANDLE COLLAR
6	W38-8101	BAIL HOLDER COLLAR	49	W46-7901	A/R LEVER
7	W38-0201	BAIL HOLDER SCREW	50	W38-6101	A/R LEVER SCREW
8	W33-7912	BAIL	51	W38-6201	DRAG METAL WASHER
9	W45-6601	LINE ROLLER WASHER	52	W38-6302	DRAG METAL A
10	W33-8202	LINE ROLLER BUSHING	53	W45-9001	DRAG WASHER B
11	W38-0602	LINE ROLLER	54	W38-6501	EARED WASHER
12	W33-8201	LINE ROLLER COLLAR	55	W38-6601	DRAG WASHER A
13	W51-5702	BAIL ARM	56	W38-6701	KEY WASHER
14	W46-4101	LINE ROLLER SCREW	57	W38-6801	DRAG COIL SPRING
15	W46-6201	BAIL ARM SCREW	58	W38-6901	DRAG SCREW WASHER
16	W38-1102	ROTOR NUT	59	W38-7001	DRAG SCREW
17	W46-4201	ROTOR NUT HOLD PLT SCREW	60	W38-7101	DRAG METAL B
18	W46-4301	ROTOR NUT HOLD PLT	61	W38-7201	DRAG COLLAR
19	W38-1901	BAIL SPRING COVER SCREW	62	W46-5401	DRAG COVER
20	W51-7801	BAIL SPRING COVER	63	W38-5901	CLICK LEAF SPRING B
21	W33-8702	BAIL SPRING SHAFT	64	W38-5001	CLICK LEAF SPRING RET
22	W38-2202	BAIL SPRING	65	W45-8701	OSC GEAR COLLAR
23	W33-8901	BAIL SPRING HOLDER	66	W34-2703	OSC GEAR
24	W56-0701	ROTOR	67	W38-5702	OSC SLIDER
25	W34-0501	BAIL TRIP LEVER SPRING	68	W46-5501	OSC SLIDER RET
26	W34-0602	BAIL TRIP LEVER	69	W38-5501	OSC SLIDER SCREW
27	W46-4501	BAIL TRIP LEVER WASHER	70	W46-5601	SIDE COVER SCREW A
28	W34-0703	BAIL TRIP LEVER SCREW	71	W56-0901	SIDE COVER
29	W46-4601	BEARING RET SCREW	72	W38-5101	CLICK LEAF SPRING A
30	W34-0901	BEARING RET A	73	W34-3802	DRIVE GEAR
31	W34-1701	BALL BEARING	74	W46-5801	A/R PAWL SPRING
32	W34-1101	BEARING RET B	75	W44-1101	A/R CAM SPRING B
33	W47-0401	BEARING RET COLLAR	76	W47-4001	DRIVE GEAR BUSHING
34	W47-0501	SPACING SLEEVE	77	W34-3701	DRIVE GEAR WASHER
35	W47-0601	PINION GEAR	78	W46-5901	A/R PAWL COLLAR A
36	W46-4901	A/R CAM SPRING A	79	W46-6001	A/R PAWL
37	W34-2003	A/R CAM	80	W34-4101	A/R PAWL COLLAR B
38	W38-4201	SIDE COVER SCREW B	81	W34-4301	A/R PAWL SCREW
39	W47-3601	REAR COVER A	82	W51-8001	HANDLE
40	W46-5101	REAR COVER B			
41	W45-9501	REAR COVER B SCREW			
42	W38-7701	O RING			
43	W46-7501	DRAG KNOB			
44	W38-7901	DRAG KNOB SCREW			


4050R Special Parts		
Key No.	Parts No.	Parts Name
1-3	W56-1001	SPOOL

# SWEEPFIRE 1550R




Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	W55-9501	FRONT DRAG KNOB	42	W34-4701	HANDLE COLLAR
1-3	W55-9601	SPOOL	43, 47	W34-5301	DRIVE GEAR BUSHING
4	W38-0301	MAIN SHAFT	44	W34-3901	A/R PAWL SPRING B
5	W34-0201	BAIL HOLDER NUT	45	W34-3801	DRIVE GEAR
6	W38-0201	BAIL HOLDER SCREW	46	W34-3701	DRIVE GEAR WASHER
7	W33-7910	BAIL	48	W55-9901	SIDE COVER
8	W38-0551	LINE ROLLER BUSHING	49	W38-5301	SIDE COVER SCREW A
9	W33-8101	LINE ROLLER	50	W45-8301	SIDE COVER SCREW B
10	W33-8201	LINE ROLLER COLLAR	51	W51-7001	HANDLE
11	W51-3702	BAIL ARM	52	W38-5101	CLICK LEAF SPRING A
12	W38-0901	LINE ROLLER SCREW	53, 60	W38-5001	CLICK LEAF SPRING RET
13	W33-8401	BAIL ARM SCREW	54	W44-1101	A/R CAM SPRING
14	W38-1101	ROTOR NUT	55	W38-5501	OSC SLIDER SCREW
15	W33-9101	ROTOR NUT HOLD PLT SCREW	56	W38-5601	OSC SLIDER RET
16	W33-9501	ROTOR NUT HOLD PLT	57	W45-8501	OSC SLIDER
17	W38-1901	BAIL SPRING COVER SCREW	58	W45-8601	OSC GEAR
18	W51-6801	BAIL SPRING COVER	59	W45-8701	OSC GEAR COLLAR
19	W45-7101	BAIL SPRING SHAFT	61	W38-5901	CLICK LEAF SPRING B
20	W45-7201	BAIL SPRING	62	W46-1901	A/R LEVER
21	W33-8901	BAIL SPRING HOLDER	63	W38-6101	A/R LEVER SCREW
22	W55-9701	ROTOR	64	W45-8801	DRAG METAL WASHER
23	W34-0501	BAIL TRIP LEVER SPRING	65	W45-8901	DRAG METAL A
24	W34-0601	BAIL TRIP LEVER	66	W45-9001	DRAG WASHER B
25	W38-2801	BAIL TRIP LEVER SCREW	67	W38-6501	EARED WASHER
26	W45-7401	BEARING RET SCREW	68	W38-6601	DRAG WASHER A
27	W34-0901	BEARING RET A	69	W38-6701	KEY WASHER
28	W34-1701	BALL BEARING	70	W38-6801	DRAG COIL SPRING
29	W34-1101	BEARING RET B	71	W45-9101	DRAG COIL SPRING WASHER
30	W34-1201	COLLAR	72	W38-7001	DRAG SCREW
31	W46-8901	PINION GEAR	73	W38-7101	DRAG METAL B
32	W45-7601	A/R PAWL COLLAR A	74	W38-7201	DRAG COLLAR
33	W45-7701	A/R PAWL SPRING A	75	W45-9201	DRAG COVER
34	W45-7801	A/R PAWL	76	W47-3001	REAR COVER A
35	W34-4101	A/R PAWL COLLAR B	77	W45-9401	REAR COVER B
36	W34-4301	A/R PAWL SCREW	78	W45-9501	REAR COVER B SCREW
38	W45-7901	A/R CAM	79	W38-7701	O RING
39	W38-4201	REAR COVER A SCREW	80	W46-2201	DRAG KNOB
40	W55-9801	BODY	81	W38-7901	DRAG KNOB SCREW
41	W48-4501	HANDLE LOCK SCREW	82	W46-2301	DRAG KNOB SCREW CAP

# CROSSFIRE 2550-3iR



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	W45-9701	FRONT DRAG KNOB	47	W38-4201	REAR COVER A SCREW
1-3	W55-8301	SPOOL	48	W55-8601	BODY
1-3	W55-8401	SPOOL (EXTRA)	49	W44-0701	HANDLE SCREW
4	W38-0301	MAIN SHAFT	50	W34-4701	HANDLE COLLAR
5	W34-0201	BAIL HOLDER NUT	51	W34-3601	BALL BEARING B
6	W38-0201	BAIL HOLDER SCREW	52	W34-3901	A/R PAWL SPRING C
7	W44-2701	BAIL	53	W46-0401	DRIVE GEAR
8	W38-0551	LINE ROLLER BUSHING	54	W34-3601	BALL BEARING C
9	W33-8101	LINE ROLLER	55	W36-3701	DRIVE GEAR COLLAR
10	W45-6601	LINE ROLLER WASHER	56	W55-8701	SIDE COVER
11	W33-8201	LINE ROLLER COLLAR	57	W38-5301	SIDE COVER SCREW A
12	W51-3701	BAIL ARM	58	W45-8301	SIDE COVER SCREW B
13	W38-0901	LINE ROLLER SCREW	59	W51-5401	HANDLE
14	W33-8401	BAIL ARM SCREW	60	W38-5101	CLICK LEAF SPRING A
15	W38-1101	ROTOR NUT	61, 68	W38-5001	CLICK LEAF SPRING RET
16	W33-9101	ROTOR NUT HOLD PLT SCREW	62	W44-1101	A/R CAM SPRING
17	W33-9501	ROTOR NUT HOLD PLT	63	W38-5501	OSC SLIDER SCREW
18	W38-1901	BAIL SPRING COVER SCREW	64	W38-5601	OSC SLIDER RET
19	W34-0301	BAIL SPRING COVER	65	W38-5701	OSC SLIDER
20	W33-8701	BAIL SPRING SHAFT	66	W34-2701	OSC GEAR
21	W33-8801	BAIL SPRING	67	W45-8701	OSC GEAR COLLAR
22	W33-8901	BAIL SPRING HOLDER	69	W38-5901	CLICK LEAF SPRING B
23	W55-8501	ROTOR	70	W34-2401	A/R LEVER
24	W34-0501	BAIL TRIP LEVER SPRING	71	W38-6101	A/R LEVER SCREW
25	W34-0601	BAIL TRIP LEVER	72	W45-8801	DRAG METAL WASHER
26	W38-2801	BAIL TRIP LEVER SCREW	73	W45-8901	DRAG METAL A
27	W45-7401	BEARING RET A SCREW	74	W45-9001	DRAG WASHER A
28	W34-0901	BEARING RET A	75	W38-6501	EARED WASHER
29	W34-1701	BALL BEARING A	76	W38-6601	DRAG WASHER B
30	W34-1101	BEARING RET B	77	W38-6701	KEY WASHER
31	W34-1201	BEARING RET WASHER	78	W38-6801	DRAG COIL SPRING
33	W34-1401	ROLLER CLUTCH	79	W45-9101	DRAG COIL SPRING WASHER
34	W45-7501	ROLLER CLUTCH COLLAR	80	W38-7001	DRAG SCREW
35	W46-1401	PINION GEAR COLLAR	81	W38-7101	DRAG METAL B
36	W46-8901	PINION GEAR	82	W38-7201	DRAG COLLAR
37	W38-3801	A/R PAWL SCREW	83	W45-9201	DRAG COVER
38	W34-4501	A/R PAWL A	84	W46-3401	REAR COVER A
39	W34-4401	A/R PAWL SPRING A	85	W47-2301	REAR COVER B
40	W45-7601	A/R PAWL COLLAR	86	W45-9501	REAR COVER B SCREW
41	W45-7701	A/R PAWL SPRING B	87	W38-7701	O RING
42	W45-7801	A/R PAWL B	88	W45-9601	DRAG KNOB
43	W34-4101	A/R PAWL COLLAR	89	W38-7901	DRAG KNOB SCREW
44	W34-4301	A/R PAWL SCREW	90	W38-8001	DRAG KNOB SCREW CAP
46	W34-2001	A/R CAM			

# REGAL 4500/5000Bri



**Key**

No.	Parts No.	Parts Name
1	W36-9501	FRONT DRAG KNOB
2	W50-2101	SPOOL
3	W36-9301	SPOOL WASHER
4	W36-9201	CLICK GEAR
5	W49-6501	MAIN SHAFT
6	W30-8701	ROTOR NUT
7	W36-8901	ROTOR NUT HOLD PLT SCREW
8	W30-6501	ROTOR NUT HOLD PLT
9	W30-8201	ROTOR NUT COLLAR
10	W49-6601	BAIL HOLDER COVER SCREW
11	W39-3702	BAIL HOLDER COVER
12	W36-8601	BAIL HOLDER SCREW
13	W49-6802	BAIL
14	W45-6601	LINE ROLLER WASHER
15	W36-8101	LINE ROLLER
16	W36-1951	LINE ROLLER BUSHING
17	W33-8202	LINE ROLLER COLLAR
18	W49-7002	BAIL ARM
19	W33-8301	LINE ROLLER SCREW
20	W36-8601	BAIL ARM SCREW
21	W49-6601	BAIL SPRING COVER SCREW
22	W39-3402	BAIL SPRING COVER
23	W39-3301	BAIL SPRING SHAFT
24	W39-3201	BAIL SPRING
25	W39-3101	BAIL SPRING HOLDER
26	W39-2801	BAIL TRIP LEVER COLLAR
27	W31-1701	BAIL TRIP LEVER SPRING
28	W39-2901	BAIL TRIP LEVER
29	W46-4501	BAIL TRIP LEVER WASHER
30	W39-3001	BAIL TRIP LEVER SCREW
31	W49-7102	ROTOR
32	W39-2601	A/R PAWL SPRING A
33	W49-7201	A/R PAWL COLLAR
34	W39-0301	BEARING RET SCREW
35	W49-7301	BEARING RET
36	W49-7401	BALL BEARING A

**Key**

No.	Parts No.	Parts Name
37	W49-7501	BEARING RET COLLAR
38	W39-2401	COLLAR
39	W34-1501	ROLLER CLUTCH WASHER
40	W49-7601	ROLLER CLUTCH
41	W50-2201	BUSHING
42	W39-1801	PINION WASHER
43	W49-7701	PINION GEAR
44	W39-1401	A/R PAWL SCREW
45	W39-1301	A/R PAWL
46	W39-1201	A/R PAWL SPRING B
47	W34-1901	A/R CAM SPRING
48	W49-7801	A/R CAM
49	W49-0801	A/R CAM RET
50	W49-7901	A/R LEVER SPRING
51	W49-8001	A/R LEVER
52	W34-0401	REAR COVER A SCREW
53	W49-8102	BODY
54	W46-5301	HANDLE SCREW
55	W30-6401	HANDLE SCREW WASHER
56	W49-8201	CLUTCH LEVER SCREW A
57	W30-9401	CLUTCH LEVER SCREW B
58	W49-8302	CLUTCH LEVER A
59	W49-8401	CLUTCH LEVER BRIDGE
60	W49-8501	BALL BEARING WASHER
61	W49-8601	BALL BEARING B
62	W49-8701	DRIVE GEAR
63	W49-8801	DRIVE GEAR WASHER
64	W49-8601	BALL BEARING C
66	W49-8902	SIDE COVER
67	W34-3201	SIDE COVER SCREW A
68	W34-3101	SIDE COVER SCREW B
69	W36-3401	SIDE COVER SCREW C
70	W50-2301	HANDLE
71	W40-2401	CLUTCH LEVER SCREW C
72	W49-9102	CLUTCH LEVER B
73	W49-9201	CLUTCH CAM

**Key**


No.	Parts No.	Parts Name
74	W49-9301	CLUTCH CAM SPRING
75	W49-9401	CLICK LEAF SPRING A SCREW
76	W49-9501	CLICK LEAF SPRING A
77	W49-9601	OSC PLT
78	W49-9701	CLICK LEAF SPRING B SCREW
79	W49-2601	CLICK LEAF SPRING B
80	W38-5501	OSC SLIDER RET SCREW
81	W49-9801	OSC SLIDER RET
82	W49-9901	OSC SLIDER
83	W30-5401	OSC GEAR
84	W30-5601	OSC GEAR COLLAR
85	W50-0001	CLUTCH PLT RET
86	W49-3401	CLUTCH PLT SCREW
87	W50-0101	CLUTCH PLT
88	W50-0201	CLUTCH TRIP LEVER
89	W50-0301	CLUTCH TRIP LEVER SPRING
90	W50-0401	DRAG METAL A WASHER
91	W50-0501	DRAG METAL A
92	W50-0601	DRAG WASHER
93	W50-0701	EARED WASHER
94	W50-0801	KEY WASHER
95	W50-0901	DRAG COIL SPRING
96	W50-1001	DRAG COIL SPRING WASHER
97	W50-1101	DRAG SCREW
98	W50-1201	DRAG METAL B
99	W50-1301	DRAG METAL B WASHER
100	W50-1401	DRAG SCREW RET
101	W50-1502	REAR COVER A
102	W50-1602	REAR COVER B
103	W49-5001	REAR COVER B SCREW
104	W50-1702	DRAG KNOB
105	W33-6301	DRAG KNOB SCREW
106	W50-1802	DRAG KNOB SCREW CAP

**5000BRI Special Parts**

2	W50-2401	SPOOL
---	----------	-------



# SPINNING REEL **REGAL PLUS 4500/5000BRi**



Key No.	Parts No.	Parts Name
1	W36-9501	FRONT DRAG KNOB
2	W49-6301	SPOOL
2	W49-6401	SPOOL (EXTRA)
3	W36-9301	SPOOL WASHER
4	W36-9201	CLICK GEAR
5	W49-6501	MAIN SHAFT
6	W30-8701	ROTOR NUT
7	W36-8901	ROTOR NUT HOLD PLT SCREW
8	W30-6501	ROTOR NUT HOLD PLT
9	W30-8201	ROTOR NUT COLLAR
10	W49-6601	BAIL HOLDER COVER SCREW
11	W49-6701	BAIL HOLDER COVER
12	W36-8601	BAIL HOLDER SCREW
13	W49-6801	BAIL
14	W45-6601	LINE ROLLER WASHER
15	W36-8101	LINE ROLLER
16	W49-6901	BALL BEARING A
17	W33-8202	LINE ROLLER COLLAR
18	W49-7001	BAIL ARM
19	W33-8301	LINE ROLLER SCREW
20	W36-8601	BAIL ARM SCREW
21	W49-6601	BAIL SPRING COVER SCREW
22	W39-3402	BAIL SPRING COVER
23	W39-3301	BAIL SPRING SHAFT
24	W39-3201	BAIL SPRING
25	W39-3101	BAIL SPRING HOLDER
26	W39-2801	BAIL TRIP LEVER COLLAR
27	W31-1701	BAIL TRIP LEVER SPRING
28	W39-2901	BAIL TRIP LEVER
29	W46-4501	BAIL TRIP LEVER WASHER
30	W39-3001	BAIL TRIP LEVER SCREW
31	W49-7101	ROTOR
32	W39-2601	A/R PAWL SPRING A
33	W49-7201	A/R PAWL COLLAR
34	W39-0301	BEARING RET SCREW
35	W49-7301	BEARING RET
36	W49-7401	BALL BEARING B


Key No.	Parts No.	Parts Name
37	W49-7501	BEARING RET COLLAR
38	W39-2401	ROLLER CLUTCH COLLAR
39	W34-1501	ROLLER CLUTCH WASHER
40	W49-7601	ROLLER CLUTCH
41	W39-1801	PINION WASHER
42	W49-7701	PINION GEAR
43	W39-1401	A/R PAWL SCREW
44	W39-1301	A/R PAWL
45	W39-1201	A/R PAWL SPRING B
46	W34-1901	A/R CAM SPRING
47	W49-7801	A/R CAM
48	W49-0801	A/R CAM RET
49	W49-7901	A/R LEVER SPRING
50	W49-8001	A/R LEVER
51	W34-0401	REAR COVER A SCREW
52	W49-8101	BODY
53	W36-0201	HANDLE SCREW
54	W30-6401	HANDLE SCREW WASHER
55	W49-8201	A/R LEVER SCREW
56	W30-9401	CLUTCH LEVER SCREW A
57	W49-8301	CLUTCH LEVER A
58	W49-8401	CLUTCH LEVER BRIDGE
59, 64	W49-8501	BALL BEARING WASHER
60	W49-8601	BALL BEARING C
61	W49-8701	DRIVE GEAR
62	W49-8801	DRIVE GEAR WASHER
63	W49-8601	BALL BEARING D
65	W49-8901	SIDE COVER
66	W34-3201	SIDE COVER SCREW A
67	W34-3101	SIDE COVER SCREW B
68	W36-3401	SIDE COVER SCREW C
69	W49-9001	HANDLE
70	W40-2401	CLUTCH LEVER SCREW B
71	W49-9101	CLUTCH LEVER B
72	W49-9201	CLUTCH CAM
73	W49-9301	CLUTCH CAM SPRING
74	W49-9401	CLICK LEAF SPRING A SCREW

Key No.	Parts No.	Parts Name
75	W49-9501	CLICK LEAF SPRING A
76	W49-9601	OSC PLT
77	W49-9701	CLICK LEAF SPRING B SCREW
78	W49-3201	CLICK LEAF SPRING B
79	W38-5501	OSC SLIDER RET SCREW
80	W49-9801	OSC SLIDER RET
81	W49-9901	OSC SLIDER
82	W30-5401	OSC GEAR
83	W34-3602	BALL BEARING E
84	W50-0001	CLUTCH PLT RET
85	W49-3401	CLUTCH PLT SCREW
86	W50-0101	CLUTCH PLT
87	W50-0201	CLUTCH TRIP LEVER
88	W50-0301	CLUTCH TRIP LEVER SPRING
89	W50-0401	DRAG METAL A WASHER
90	W50-0501	DRAG METAL A
91	W50-0601	DRAG WASHER
92	W50-0701	EARED WASHER
93	W50-0801	KEY WASHER
94	W50-0901	DRAG COIL SPRING
95	W50-1001	DRAG COIL SPRING WASHER
96	W50-1101	DRAG SCREW
97	W50-1201	DRAG METAL B
98	W50-1301	DRAG METAL B WASHER
99	W50-1401	DRAG SCREW RET
100	W50-1501	REAR COVER A
101	W50-1601	REAR COVER B
102	W49-5001	REAR COVER B SCREW
103	W50-1701	DRAG KNOB
104	W33-6301	DRAG KNOB SCREW
105	W50-1801	DRAG KNOB SCREW CAP

**5000BRi Special Parts**

2	W50-1901	SPOOL
2	W50-2001	SPOOL (EXTRA)

# SPINNING REEL **EMCAST SPORT 5500/6000**



Key No.	Parts No.	Parts Name
1	W52-4103	BODY
2	W36-0202	HANDLE SCREW
3	W36-0101	HANDLE WASHER
4	W52-6901	A/R LEVER
5	W36-0401	A/R LEVER SCREW
6	W36-0501	REAR COVER RET
7	W36-0601	REAR COVER A SCREW
8	W52-6301	REAR COVER A
9	W52-6401	REAR COVER B
10	W36-0901	REAR COVER B SCREW
11	W36-1001	WORM SHAFT RET
12,14	W36-1101	WORM SHAFT BUSH
13	W36-1201	WORM SHAFT
15	W36-1401	A/R CAM SPRING A
16	W36-1501	STABILIZER BAR
17	W36-1601	STABILIZER BAR SCREW
18	W36-1751	OSC SLIDER BUSHING
19	W36-1801	OSC SLIDER
20	W42-9401	BALL BEARING A
21	W36-2001	OSC SLIDER RET
22	W36-2101	OSC PAWL
23	W36-2201	OSC PAWL COLLAR
24	W36-2301	OSC PAWL WASHER
25	W36-2401	OSC SLIDER COVER
26	W36-2501	OSC SLIDER COVER SCREW
27	W52-5301	WORM SHAFT RET
28	W36-2701	WORM SHAFT GEAR
29	W42-9301	BALL BEARING B
30	W52-5401	A/R PAWL SPRING A
31	W36-3001	DRIVE GEAR
32	W50-8701	DRIVE GEAR WASHER
33	W42-9301	BALL BEARING C
34	W52-4403	SIDE COVER
35	W36-3301	SIDE COVER SCREW A
36	W36-3401	SIDE COVER SCREW B
37	W52-6501	HANDLE
38	W36-3601	A/R PAWL A

Key No.	Parts No.	Parts Name
39	W36-3701	A/R PAWL COLLAR
40	W36-3801	A/R PAWL RET
41	W36-3901	A/R PAWL SPRING B
42	W36-4001	A/R PAWL B
43	W36-4101	A/R PAWL B SCREW
44	W36-4201	REAR COVER SCREW B
45	W36-4301	A/R CAM
46	W36-4401	PINION RET
47	W36-4501	A/R RATCHET
48	W36-4601	RATCHET WASHER
49	W36-4701	BALL BEARING D
50	W36-4801	PINION GEAR
51	W36-4901	PINION GEAR COLLAR
52	W36-5001	PINION WASHER
53	W36-5101	ROLLER CLUTCH
54	W36-5201	ROLLER CLUTCH WASHER
55	W36-5301	ROLLER CLUTCH COLLAR
56	W36-5401	BEARING RET A
57	W42-9201	BALL BEARING E
58	W36-5501	BALL BEARING RET WASHER
59	W36-5601	BEARING RET B
60	W36-5701	BEARING RET B SCREW
61	W36-5801	BALL BEARING F
62	W36-5901	BALL BEARING COLLAR A
63	W36-6001	SPACING SLEEVE
64	W36-6101	MAIN SHAFT SPRING A
65	W36-6201	MAIN SHAFT COLLAR
66	W36-5801	BALL BEARING G
67	W36-6301	BALL BEARING WASHER A
68	W36-6401	BALL BEARING WASHER B
69	W36-6501	MAIN SHAFT SPRING B
70	W36-6601	BAIL TRIP LEVER SCREW
71	W31-1801	BAIL TRIP LEVER WASHER
72	W36-6801	BAIL TRIP LEVER
73	W36-6901	BAIL TRIP LEVER SPRING
74	W36-7001	BAIL SPRING HOLDER

Key No.	Parts No.	Parts Name
75	W36-7101	BAIL SPRING
76	W36-7201	BAIL SPRING SHAFT
77	W52-6601	BAIL SPRING COVER
78	W36-7401	BAIL SPRING COVER SCREW
79	W36-7501	BAIL ARM SCREW
80	W36-7601	LINE ROLLER SCREW
81	W52-4603	BAIL ARM
82	W30-6201	LINE ROLLER WASHER A
83	W30-6101	LINE ROLLER WASHER A
84	W36-8051	LINE ROLLER COLLAR
85	W36-8101	LINE ROLLER
86	W36-8203	BAIL
87	W52-4703	ROTOR
89	W36-8401	BAIL HOLDER SCREW
90	W52-6701	COVER
91	W36-8601	BAIL HOLDER COVER SCREW
92	W36-8701	MAIN SHAFT NUT
93	W36-8801	ROTOR NUT HOLD PLT
94	W36-8901	ROTOR NUT HOLD PLT SCREW
95	W36-9001	MAIN SHAFT
96	W36-9101	LINE GUARD
97	W36-9201	CLICK GEAR
98	W36-9301	CLICK GEAR WASHER
99-103	W52-4803	SPOOL
100	W36-9601	DRAG WASHER
101	W36-9701	KEY WASHER
102	W36-9801	EARED WASHER
103	W36-9901	DRAG WASHER RET
104	W52-6801	DRAG KNOB
105	W50-3301	SIDE COVER SCREW C
106	W50-3001	CLUTCH COVER SCREW
107	W50-3101	SPOOL WASHER
108	W50-3201	A/R CAM SPRING B

**ECS6000 Special Parts**  
99-103 W52-5002 SPOOL