




PARTS LIST FOR MODEL 525MAG



KEY NO.

KEY NO.	DESCRIPTION
1	Right Side Plate
2	Right Side Ring
4	Fiber Washer
5	Main Gear
6	Friction Drag Washer (3 req.)
7C	Metal Drag Washer (3 req.)
8	Tension Spring Washer
10	Drag Star
11	Eccentric Jack
12	Pinion Yoke
13	Pinion Gear
18	Tension Spring Washer
18B	Clutch Spring (2 req.)
19	Eccentric
20	Eccentric Spring

PART NO.

PART NO.	DESCRIPTION
001 525MAG	Right Side Plate
002 525MAG	Right Side Ring
004 60	Fiber Washer
005 525MAG	Main Gear
006 525MAG	Friction Drag Washer (3 req.)
086 049L	Metal Drag Washer (3 req.)
008 60	Tension Spring Washer
010 525	Drag Star
011 525	Eccentric Jack
012 555	Pinion Yoke
013 525MAG	Pinion Gear
018 505	Tension Spring Washer
018 525	Clutch Spring (2 req.)
019 525	Eccentric
020 525	Eccentric Spring

KEY NO.

KEY NO.	DESCRIPTION
20A	Ball Bearing
21	Eccentric Lever
22	Eccentric Screw
23	Handle Nut
24	Handle
26B	Spool Tension Control Cap
27	Left Side Plate
28	Left Side Ring
29L	Aluminum Spool
32	Frame Post Screw (4 req.)
32A	Handle Lock Screw
33	Rod Clamp
34	Rod Clamp Screw (2 req.)
34C	Rod Clamp Screws w/Nuts
35	Click Tongue
36	Click Button
37	Frame Post (2 req.)
39S	R/L Side Plate Screw (2 req.)
40C	Metal Thrust Washer
40D	Rubber Thrust Washer
43B	Magnet Housing Screw
46	Side Plate Screw (2 req.)
55	R.S. Spool Ball Bearing (2 req.)
55A	Ball Bearing
62A	Click Spring (2 req.)
62B	Click Pin (2 req.)
62C	Click Spring Cover
63	Retainer Screw (3 req.)
69B	Retaining Ring
71B	Clutch Plate
71C	Clutch Plate Retainer
71L	Spool Spindle
81	Click Ratchet
98B	Anti-Reverse Bearing
98R	Ratchet Spacer
98S	Clutch Shaft
110	Side Plate Short Screw
110A	Handle Nut Lock Cap
120	O-Ring
121	Bearing Screw
134	Gear Stud
149	Rod Clamp Nut (2 req.)
149A	Rod Clamp Hex Nut (2 req.)
173	Bearing Retainer
183	Frame
302	Magnet Housing
302B	Magnet Control Button
302C	Magnet Ramp
302D	Magnet Spring (2 req.)
303	Magnet Button Screw

PART NO.

PART NO.	DESCRIPTION
020 722	Ball Bearing
021 525	Eccentric Lever
022 310	Eccentric Screw
023 555	Handle Nut
024 555	Handle
026B555	Spool Tension Control Cap
027 525MAG	Left Side Plate
028 525MAG	Left Side Ring
029L525MAG	Aluminum Spool
032 310	Frame Post Screw (4 req.)
032 015	Handle Lock Screw
033 113	Rod Clamp
034 045	Rod Clamp Screw (2 req.)
034C045	Rod Clamp Screws w/Nuts
035 525MAG	Click Tongue
036 525	Click Button
037 525	Frame Post (2 req.)
039 525	R/L Side Plate Screw (2 req.)
040C555	Metal Thrust Washer
040D555	Rubber Thrust Washer
043B965	Magnet Housing Screw
046 4300	Side Plate Screw (2 req.)
055L965	R.S. Spool Ball Bearing (2 req.)
055 113H	Ball Bearing
014 040	Click Spring (2 req.)
062B525MAG	Click Pin (2 req.)
062C525	Click Spring Cover
063 500S	Retainer Screw (3 req.)
069B600	Retaining Ring
071B525MAG	Clutch Plate
071C525MAG	Clutch Plate Retainer
071L525MAG	Spool Spindle
081 525MAG	Click Ratchet
098B525	Anti-Reverse Bearing
098 525	Ratchet Spacer
098S525	Clutch Shaft
110 050	Side Plate Short Screw
110A555	Handle Nut Lock Cap
120 113H	O-Ring
121 525	Bearing Screw
134 525	Gear Stud
149 045	Rod Clamp Nut (2 req.)
149 200	Rod Clamp Hex Nut (2 req.)
173 525	Bearing Retainer
183 525MAG	Frame
302 525MAG	Magnet Housing
302B525MAG	Magnet Control Button
302C525MAG	Magnet Ramp
302D525MAG	Magnet Spring (2 req.)
303 525MAG	Magnet Button Screw