


BAITCASTING REEL — Millionaire M35-2B/M37-2B



Key No.	Parts No.	Parts Name
1	K16-2303	Left side plate assembly
2	K16-9102	Left side plate screw
3	K16-4202	Click button
4	K16-4101	Click button washer
5	K16-3701	Click set plate
6	K16-4301	Click pawl
7	K16-4403	Click pawl washer
8	320-5901	Click pawl retainer
9	K16-4501	Click pawl spring
10	320-5901	Click button retainer
11	K16-4001	Click set plate spring
12	K16-3901	Click set plate pin
13	K16-3801	Click pawl nut
14	K16-3501	Idle gear
15	K16-3601	Idle gear retainer
16	K16-4601	Spacer A
17	K16-4701	Frame assembly
18	K16-7301	Stabilizer bar
19	K15-9801	Stabilizer bar spring washer
20	320-5901	Stabilizer bar retainer
21	K16-6301	Worm shaft
22	K16-6801	Worm bearing A
23	K16-5701	Level wind guard
24	K16-6001	Line guide
25	K16-5901	Worm bearing B
26	K16-4403	Worm shaft holder washer
27	320-5901	Worm shaft retainer
28	K10-7001	Line guide pawl
29	K16-7101	Line guide washer
30	K16-7201	Pawl cap

Key No.	Parts No.	Parts Name
31	B33-9801	Bearing retainer
32	K16-8801	Spool gear
33	K16-8701	Bushing
34	K16-9001	Brake collar
35	K16-7601	Spool assembly
36	K15-8501	"O" ring
37	K15-8701	Bushing
38	K15-7201	Set plate assembly
39	K15-9501	Anti-reverse pawl
40	K15-8801	Set plate spring A
41	320-1402	Clutch retaining ring
42	K15-8901	Set plate spring B
43	K15-9101	Pinion gear
44	K15-9001	Yoke
45	K15-9401	Yoke spring
46	K15-6004	Right side plate assembly
47	K15-6701	Bush
48	K15-6601	"O" ring
49	K15-6801	Spacer B
50	K15-6901	Spool tension spring
51	K15-7002	Cast control cap
52	K16-0902	Set plate screw
53	K15-9801	Drive shaft washer A
54	K15-9901	Drive shaft
55	K16-0001	Anti-reverse-ratchet
56	K16-0101	Drive shaft washer B
57	K16-0201	Drive gear
58	K16-0102	Drag washer A
59	K16-0401	Key washer A
60	K16-0501	Eared washer